

Internal Pole Kits:

Spacevac offer 3 options for Internal cleaning pole sets:

38mm Classic



SV38/16-Classic
5 x 38mm x 1.6m
classic pole



SV38/08-Classic
1 x 38mm 0.8m Classic
half pole



SV/PB
1 x Pole bag

38mm Pro



SV38/16-Pro
7 x 38mm x 1.6m Pro
pole



SV38/08-Pro
1 x 38mm 0.8m Pro half
pole



SV/PB
1 x Pole bag

38mm Ultra:



SV38/16-Ultra
9 x 38mm x 1.6m Ultra
pole



SV38/08-Ultra
1 x 38mm 0.8m Ultra
half pole



SV/PB
1 x Pole bag

“The Church hasn't looked so good in years - definitely something of a revelation”

Michael Macey, St Johns, Boxmoor



SpaceVac Internal system in action, Hemel Hempsted [UK]

Once you have selected your pole set, each SpaceVac Internal cleaning system comes equipped with the following:

Hose Kit:



SV38/5H
1 x 5m Hose



SV38/HA
1 x Pole to Hose Adaptor



SV38/50HC
1 x 38mm Hose to Vac Cuff



SV/HB
1 x Hose Bag

Head Kit:



SV38/8SW
1 x 8" Flexi Brush



SV38/15SW
1 x 15" Flexi Brush



SV38/FLT
1 x Flat surface brush



SV38/12DB
1 x 12" Ducting Brush



SV38/5RB
1 x Small round brush



SV38/45H
1 x 45 degree cleaning head



SV38/90H
1 x 90 degree cleaning head



SV38/135H
1 x 135 degree cleaning head



SV38/STR
1 x Straight head



SV/MB
1 x Mesh Bag

Camera Kit:




SV/CAM
1 x Camera



SV/MON
1 x Monitor



SV/CC
Camera Clip



SV/MC
1 x Monitor Clip



SVCAM/CAR
1 x Car Charger



SVCAM/USBCHARGE
1 x USB Charger Cable



SVCAM/SPLITTER
1 x Splitter Cable



SVCAM/USB
1 x USB Data Cable



SVCAM/CB
1 x Camera Bag

www.proequip.be

Check out our accessories section to find a range of tools and add-on's to the SpaceVac Internal Cleaning system